




The J2534 driver must be downloaded to your PC to allow communications with the VCI.

**NOTE:**


- In order to complete a successful programming event, you must follow the OEM programming requirements on the OEM J2534 website.
- For information on OEM Reprogramming Web Sites and PC requirements, go to the ASA OEM Resource Center at [oerepairinfo.com/](http://oerepairinfo.com/).

### VCI Driver Installation Procedure




1. To download J2534 drivers, visit [www.boschdiagnostics.com](http://www.boschdiagnostics.com), navigate to the Software Updates and Downloads page, and select your Product model. Included are the J2534 drivers and related information.
2. After the J2534 driver is downloaded to the PC, run the MRVCIPlus.exe file from the download location.




3. Select the language from the list of choices offered in the drop down menu. Select **OK**



4. If Microsoft Visual C++ 2005 Redistribution package has not been installed on the PC previously, a prompt to install it now opens. Select **Install**.




5. A prompt to ensure that VCI applications are not running and VCI is not connected to a PC is shown. When confirmed, Select **OK**.




8. It is recommended to install the file in the default location. Select **Next**.


### 32-bit PCs




6. At the Welcome screen, Select **Next**.





### 64-bit PCs




7. Read the Software Product License Agreement. Select the **"I accept the terms in the license agreement"** choice and Select **Next**.




9. Select **Install** to start the installation.



10. If a warning dialog box appears select **Install**.



11. The installation is successfully completed. Select **Finish** to exit.



**Bosch Technical Support: (855) 267-2483**

Please record and retain this important information: